CAMILLE

CHARACTERISTICS









SHELL

SIDES BACK BASE TOP

Unit/structure:



Pre-assembled melamine unit comprising 4/6/9/12 locker compartments

Materials: Particle board panels covered on both sides with melamine overlay

Density: 620 to 690 kg/m3

Thickness: 19 mm

Stabiliser feet: Ø 48 mm, adjustable through 15 mm



- > Single compartment dimensions: W. 374 x H. 349 x D. 390 mm. Double compartment dimensions: W. 374 x H. 715 x D. 390 mm.
- > Melamine shelves (19 mm thick). Maximum load per shelf: 20 kg.
- > Single compartment: Fits a motorcycle helmet or a 17-inch laptop.
- > Double compartment: Fits a cabin-sized suitcase. A shelf can be fitted to split the compartment in half (see options).



Shelves:

> Supplied loose; to be fitted according to configuration (single/double compartments)



Unit back panel:

- > Perforated back panel to provide ventilation for each compartment
- > 5 holes per compartment, in a cross shape spacing 32 mm $\,$ hole diameter 5 mm

DOORS

METAL DOORS



Materials: Sheet steel with lacquered epoxy finish

Thickness: 1 mm

Format: Single door (H. 344 / W. 369) or double door (H. 712 / W. 369)

Finish: Dot pattern, with or without mail slot (dimensions 20 x 262.5 mm, so mail can be posted without opening the door)





- > Soft-closing hinges
- > Door opening angle: 107° (allows adjacent door to be opened simultaneously)
- > End-of-travel stop to be fitted

MELAMINE DOORS



Materials: Particle board panels covered with melamine overlay

Density: 620 to 690 kg/m3

Thickness: 19 mm

Format: Single door (H. 344 / W. 369) or double door (H. 712 / W. 369)

/!\For the 2 compartment version (= double door), the partition shelf must be removed during assembly so that the large door can be fitted. If you wish to divide the space in 2 on the inside, a new shelf is required (sold as an option)

Decor: Melamine - please refer to the CAMILLE melamine colour chart

Finish: Melamine - see CAMILLE melamine shade card

Opening/closing:

- > Hinges on right-hand side
- > End-of-travel stop to be fitted Soft-closing hinges.
- > Door opening angle:

107° (allows adjacent door to be opened simultaneously)

> Version with mail slot: Door is shorter by 29 mm, so that mail can be posted through the top of the door.

Combination lock (available for all doors):

Materials: Shell and front casing made from polymer.

Type: Horizontal with cam - 4-digit code - Closing at 90° rotation - Ergonomic knob.



LOCKS

Set-up and operation: Colour indicators: open (green), closed (red), change code (blue). 2 operating modes: private or public (factory setting). Configuration is done with the door open. The device for switching from public to private (or vice versa) is on the rear part of the lock. See instructions for setting a personal code.

Other: A master key that opens all the doors can be ordered separately (see options).

Lock dimensions: W. 77 x H. 27 x D 253 mm The lock must be installed on the door.

Key-operated lock (only available for melamine doors):

Type: Horizontal with cam - Single-point lock - Closing at 90° rotation

Description: 1 standard key + 1 folding key

Other: A master key that opens all the doors can be ordered separately (see options).

The lock must be installed on the door.



BASE/LEG OPTIONS

4 FEET

 $\Theta \Theta \Theta \Theta$

• Square section plastic feet 75 x 75 mm, H. 50 mm, in an Aluminium grey finish

BASE

Materials: Metal.

Thickness: Rectangular section tube 30 x 60 mm + round tube Ø 40 mm

• Metal base with 4 legs H. 200 mm. Fastened to the underside of the locker unit using inserts.

The base is slightly narrower than the unit.

> Base W. 726 x D. 352 mm for 4- or 6-compartment units (overall dimensions)

> Base W. 1119 x D. 352 mm for 9- or 12-compartment units (overall dimensions)

OTHER OPTIONS

LETTER TRAY



Materials: Metal (1.5 mm thick)

Description: Can be fitted on metal or melamine doors with a mail slot (2 different models):

> For melamine doors (single or double): letter tray with label holder (paper labels not supplied). W. 242 x H. 324 x D. 72 mm. Hangs on the

> For metal doors (single only): letter tray must be mounted on the back of the door. W. 300 imes H. 294 imes D. 70 mm.

MELAMINE SHELF



Materials: Melamine-covered particle board panel

Description: For double-door compartments, to split the compartment in half

Dimensions: W. 374 x D. 359 x thickness 19 mm

MASTER KEY

Description:

Set of 2 master keys to open all locks (2 sets available: one for combination locks, one for key-operated locks). To be assigned to the manager(s) in charge of the lockers. To order master keys for key-operated locks, consult us.











		LOCKER UNITS		
OVERALL DIMENSION	NS (in mm)			
	4-compartment unit	6-compartment unit	9-compartment unit	12-compartment unit
Depth	432	432	432	432
Width	807	807	1200	1200
Height	755	1123	1123	1491
Height with ABS feet	805	1173	1173	1541
Height with metal base	955	1323	1323	1691
USABLE DIMENSIONS) :			
Single compartment				
Depth	390			
Width	374			
Height	349			
Double compartment				
Depth	390			
Width	374			
Height	715			
WEIGHT (kg)				



Max. load

per shelf







30 kg





ADDITIONAL INSTRUCTIONS

PERSONAL CODE SETTING

Several people can use the same locker in turn, with a code set by each user. The last user must leave the lock open so that the next user can set a new code.

IMPORTANT: The factory setting is public mode. To switch to use in private mode, follow the instructions in the paragraph. The code must be set at door open.

USE IN PUBLIC MODE

Position the arrow of the selector on "CHANGE"



Set your personal code (example: 2017)



Position the arrow of the selector on "CLOSE"



Hide the code by turning the 4 digits to a different combination

THE DOOR IS CLOSED, YOU DON'T KNOW THE CODE. HERE IS HOW TO OPEN IT:

- 1. Insert the key (pass) and make a 1/2 turn to the right
- 2. turn each number until it locks
- 3. turn the key 1/2 turn to the left
- 4. remove the key
- 5. turn the knob and open the door.

PRIVATE CODE SETTING

Only 1 person has access to a locker thanks to a personal code set up by himself.

IMPORTANT: the personal code must be set at door open.

USE IN PRIVATE MODE

Position the arrow of the selector on "OPEN"



Position the back cursor on the position "3. CODE RESET"



Position the selector arrow on "CHANGE" and set your personal code (example: 2017)



Position the arrow of the selector on "CLOSE"



Position the back cursor on the position "1.PERSONAL"



Position the arrow of the selector on "OPEN"



If you wish to set a new code, repeat the same operation.